



Crane Certification Operator Requirements for Construction Work



Larry Markee, Crane Technical Specialist Department Of Labor and Industries Division of Occupational Safety and Health

















Cranes Included Equipment Excluded Crane Certification Crane Operator Qualifications Crane Certifier Accreditation





What's Included ?

This rule applies to power-operated cranes and derricks <u>used in construction</u> that can hoist, lower and horizontally move a suspended load (with or without attachments). Such equipment includes, but is not limited to:






Mobile Cranes









Rough-Terrain Cranes







Hydraulic Boom Truck Cranes







Carry-Deck Cranes







Lattice Boom Truck Cranes







Crawler Cranes









Tower Cranes







Articulating Boom Cranes







Derricks







Dedicated Pile Drivers







What's Excluded ?

The following equipment is exempt from Annual Crane certification & Operator Certification





Exempt

Mechanic's truck when used for equipment maintenance or repair work







Certification Not Required

Cranes with a maximum capacity of one ton or less.

Service trucks with booms that rotate manually







Power Shovels







Excavators







Backhoes







Telehandlers / Forklifts







Machines with booms that are limited to up & down movement only and does not rotate









Conveyors







Crane & Operator Certification Not Required When....



Used in manufacturing facilities or powerhouses while used in routine maintenance and repair work





Crane Certification Requirements Mobile Articulating Overhead Derricks *Tower **Annually Inspection** Certification **Proof Load Test:** *annual certification after each assembly jumping, etc.)





Certification Requirements

Quadrennial Proof Load Test / Annual Inspection

Crane Components, such as Boom Sections, Back Mask Sections, Luffing Booms, Jibs, Jib Sections





Additional Tower Crane Certification Requirements

Annual Inspection, Certification, & Proof Load Test &

Tower cranes and tower crane assembly parts must be inspected by the crane certifier, prior to assembly and following erection of the tower crane, after each climbing operation, or reconfiguring the boom, jib, or counterjib before placing the crane in service.





Crane Certification





Accredited Construction Crane Certifiers

Currently 57 Certifiers

Mobile	5
Tower	1
Articulating	3
Overhead	3

CONSTRUCTION CRANE CERTIFIERS

T - Indicates TOWER CRANE ACCREDITED

M- Indicates MOBILE CRANE AND DERRICK

ACCREDITED

O - Indicates OVERHEAD CRANE ACCREDITED

A - Indicates ARTICULATING CRANE ACCREDITED

ARXCIS INC. – (T/M/O/A) PO BOX 689 KINGSTON WA 98346-0689 PHONE 360-297-3693 or 206-343-3459 FAX 360-297-8388 info@arxcis.com

STEVEN E. BRADLEY – (O) PO BOX 13157 MILLCREEK WA 98082 PHONE 425-418-8308 bradley.steve@verizon.net

BRODEK CRANE INSPECTIONS – (M) PO BOX 7089 CHANDLER AZ 85226 (480) 732-1369 ron@brodekcrane.com

CRANE AMERICA – (M/O/A) 2903 NE 109TH AVENUE SUITE A VANCOUVER WA 98682 PHONE 360-256-6385 FAX 360-256-6638 casportland@craneamerica.com

LAST UPDATED 12/2009

RICK M. DAVIS – (M) 1008 LAMBERT COURT CLARKSTON WA 99403 PHONE 509-758-8818 kpd@lewiston.com

DELCON CRANE CERTIFICATORS INC – (M/O/A) PO BOX 2727 KIRKLAND WA 98083 PHONE 800-800-4913 delconcrane@live.com

EAGLEDALE HOIST & DRAY - (M/O/A) 5432 NEW SWEDEN AVENUE BAINBRIDGE ISLAND WA 98110 PHONE/FAX 206-842-3051 CELL 206-300-8201 waltballcranes@msn.com

KENT CRANE INSPECTION SERVICES – (T/M/O/A) 4811 SOUTH 150[™] STREET TUKWILA WA 98188 PHONE 206-321-1806 FAX 206-439-6816 randy.kent@kentengineering.com


MARINE SURVEYORS & CONSULTANTS (M/O/A) PO BOX 22123

http://www.lni.wa.gov/Safety/Topics/AtoZ/Cranes/files/ConstructionCraneCertifiers.pdf





Crane / Component Identification Sticker







Temporary certificate of operation.

Accredited crane certifiers will issue a temporary certificate of operation if upon inspection and load proof testing no deficiencies were found that would affect the safe operation of the crane. WAC 296-155-53114 (1)

A copy of the crane worksheet, completed by the accredited certifier will act as a temporary certificate of operation until the annual certificate of operation is issued by the Department.

The temporary or annual certificate of operation must be posted in the operator's cab or with the operator's manual. WAC 296-155-53114 (7)

PO Box 44 Olympia V	#30 VA 98584-	eal Safety - 4650 Lei.wo.pov	Office	(341) 90			0		Mol			s/Derrick ruction I			for		
Name of Owner (Not Leaves) BELLES TOW CRANE SERVICE							Permanent Sticker ID # C0000002				Inspection Exp. Date 3/13/10			Proof Load Test Exp. Date 3/13/10			
Address City								Zi	Times			Certification to this address					
		ed or Rent	ed 🗌 Ye				rite L	essee's Nat									
	100.000000							19712-0620	100000	22201-0		☐ Send	Certifica	dion to thi	address		
Descript		Bydra	die Boom		iculatio	ng Be	on I	Derrick		er			Owner 14				
⊠ Lattice Boom □ Hydraulic Boom □ Art Manufacturer LINKBELT				Max Rated Capadi 200.001 LBS			fiy in Lbs	ty is Lbs Model Namba HC-218A		aber Serial Number 18H7-559B		Hour Meter Reading 99.01					
Site Add			-		-	-	0	~				State Zi					
		E, BLDO				_	1.0	HEHALP		and a first		WA 99		-			
		ine of Ins						N		some typ	e, sre	ast, Stiff-leg, A	-270816	496			
Wire Wire	ist: 110	No. Par	Whip: 1 ts Dia	aneter		Jib: J Stran		Wires per		Type	Cure	Break Streng	ria	Attach M	ch Mfe		
Main Ho		4		/8*		6		26		IWI		\$9.89	Cert. of Wire Repo		Rope		
Whip		1	_	7/811		6		26		IWRC		39.80	I I'm No				
Baces		23.8		5/8"	6(ALT	2	26 (A)	LT)	IWI		17.9		Vertificate Available			
Boom Pa	edants	235		3/8"	15 15 10 10	6 ten	19993	26	oficable.	IWF Mast o		\$3.5 He, so inshorte		1.69	1.40		
			. ic juin	Accep	a Re	Inct	DV.A.	1	3.0000	(3) more	in the second	and so manaded	Accept	Reject	NIA		
n) Boom			X	1	100	12.00	p) Beal		s ols/Functions/Labeled			X	1	1000			
b) Boom Extensions, Jib c) Boom Sheaves			X	-								8					
d) Fire Extinguisher			X				 r) Electrical Equipme s) Ladders, Iland Gui 			Guards, Rails, Windows		X		-			
e) Fluid Levels			X				 t) Gauges working u) Data plates / warning signs, de- 				St. 1999	X		1			
f) Fluid Lenks			2						signs,	dreab	X	1	-				
g) Guards h) Hoist Drum			X	-	v) Housekeeping w) Lights / Signa												
i) Hosk(x)			x					a) Limit Switches				X	1				
			X			1	y) Pennant Bars / Cables and Links.					X					
			X	-	-	-	 z) Load Charts and Operator's Manual aa) Operational Aids 					X	-	-			
			- X	-	-	-		erational ekand L		lors		X	1	-			
n) Anti-Two-Block Device			X				er) Ch	asis, Tirr	s, Steer	Steering							
TEST RD								acturer's los		and man	t be at l	east 100% but n f kont 25% in es					
load 5 ton	is escess;	over 50 tes	s = 10% is	OCCUPAN.	2.2.3			0.000									
Radius	Boom	Tom	Capacity Lbs.		Test	Loui		Load Ma Test's W			Crane Configuration & Test Range						
In feet 96'	11.8	100	14300		8	s Lbs. 16000		112%			OVER FRO			NT 180 DEGREES			
100*	degives		12460		5	14000		112%						LIMITED SWING			
	2			-	-			-									
Moorer	Application	on of Pres	flord	-			_	_		11.0	da for	Assigned Load	Rating	-			
		an or rive										Owner Date		Manufact	une 🖂		
Remarks						-		_				the second s					
I for	Construc	tion Oper-	ations, W	AC 296-	158. A	copy	of thi	is workshe	et will be	used as	a ir mp	h the Washing porary certific					
- eer	tification	is isward. 1	This temp	orary co	rtificat	ie in T	alid fo	or 30 days	after the o	date of t	this ins	pretion					
Date: Accredited Certifier's Name (plea 3409 ROGER DODGER						ase pri	rint) Accredit 444					d Certifier's ID #					
Certilier's Phone # Signature of Accredited Certilier 885-999-5999 Rogen & Dodgen							Address					ANE. 3 FARE SR. SEATTLE, WA 1998					





Annual Text/Examination Certificate

Certificates of operation issued by the department under the crane certification program established in this section are valid for one year from the effective date of the temporary operating certificate issued by the certified crane inspector.

The annual certificate of operation must be posted in the operator's cab or with the operator's manual

WAC 296-155-53114(7)

Department of Labor and Indu	estries
Division of Occupational Salety	& Health
PO P/ix -14650	
Olympia WA 98204-4550	
(369) 902 4943	



Date of I	Issue 01/04/2010					
COAST CRANE /PASCO						
525 S OREGON AVE						
PASCO, WA 99301						
Certificate Expiration Date	CRANE ID # C0005936					
12/21/2010	OWNER'S ID # BT133					
Certified for "On Rubber" Use: No						
Location: 525 S OREGON AVE PASCO 99301	Model #: 800D					
Crane Type: MOBILE	Serial #: 291139					
Maximum Capacity: 46000.00 FBS.	Manufacturer: NATIONAL					

The Department of Labor and Industries, Division of Occupational Safety & Health certifies that any deficiencies considered to constitute an unsatisfactory condition have been corrected and that the device was tested and examined by the certified inspector and that said test and examination met with the requirements specified in WAC 296-155

CERTIFIED BY: GARY NEAL

EMPLOYER: COAST CRANE COMPANY/ WA

CERTIFIER 1D #: 104306

IN ACCORDANCE WITH WAC 296-56, 304 or 155, THIS CERTIFICATE SHALL BE POSTED IN OPERATORS CAB OR AT OPERATORS WORK STATION.

Components inspected with this crane are listed on the following page(s).





Certified Construction Cranes

- **§** Certified Cranes 1456
- **§** Mobile 1195
- **§** Articulating 178
- **§** Tower 51
- **§** Derrick 1
- **§** Overhead 31

» 3/19/2010





Construction Crane Operators

Qualifications & Requirements







Operator Qualifications & Certification

- **§** The crane operator must:
- S Have a valid crane operator certificate, for the type of crane to be operated, issued by a crane operator testing organization accredited by a nationally recognized accrediting agency; and
- **§** Has crane hours of experience ; and
- § Passed a substance abuse test conducted by a recognized laboratory.

» WAC 296-155-53300(1)(a)





Accredited Crane Operator Testing Organizations

- Solution Stational Commission for the Certification of Crane Operators (NCCCO) http://nccco.org/
- S Crane Institute of America Certification (CIC) http://www.craneinstitutecertification.com/
- Solution Structure Stru

Soperating Engineers Certification Program (formerly the Southern California Crane & Hoisting Certification Program) http://www.iuoe.org/Training/Local12Training/tabid/141/Default.aspx






Crane Operator Qualification Requirements

•Crane operators must recertify at least every 5 years





Crane Operator Testing Originations



National Commission for the Certification of Crane Operators



Crane Institute of America Certification



National Center for Construction Education and Research




Local 12, The International Union of Operating Engineers.





Crane Operator Certification Card

CCO Certification Card FACT SHEET



IMPORTANT

- NCCCO Certification Card Is valid only in conjunction with a current DOT or NCCCO Medical Certificate
- Verify certification is current and in the appropriate crane categories
- Check card for irregularities
- Never accept a photocopy of a CCO card as proof of certification
- Contact NCCCO If in doubt!



National Commission for the Certification of Crane Operators • 2750 Prosperity Avenue, Sulte 505 • Falifax, VA 22031 • (703) 560-2391 • www.nccco.org





Crane Categories and Types LBT- Lattice Boom Truck Crane **LBC-** Lattice Boom Crawler Crane **TLL-** Large Telescopic Boom Crane (Swing Cab) **TSS-** Small Telescopic Boom Crane (Fixed Cab) **TOW-** Tower Crane **OVR-** Overhead Crane





Lattice Boom Cranes

Truck Mounted

Crawler







Large Telescopic Boom Crane (Swing Cab)







Small Telescopic Boom Crane (Fixed Cab)









Articulating Cranes





Note: NCCCO has completed written and practical exams for articulating cranes.





Derrick

Derrick Operators must have a Lattice Boom Certification







Tower Cranes

Hammerhead

Luffing

Self-Erecting







Crane Operator Hours of Experience Table 1

The 5 Categories of Cranes and their Types	Number of Hours of Actual Crane Operating Experience	Number of Hours of Crane Related Experience
a) Lattice Boom Crawler Cranes	300 tons and above	300 tons and above
(LBC)	1000 Hours	1000 Hours
	Under 300 tons	Under 300 tons
	500 Hours	500 Hours
b) Lattice Boom Truck Cranes	300 tons and above	300 tons and above
(LBT)	1000 Hours	1000 Hours
	Under 300 tons	Under 300 tons
	500 Hours	500 Hours
 arge Telescopie Beom 	Over 130 tons	Over 130 tons
Cranes (Swing Cab) (TLL)	750 Hours	750 Hours
	Over 40 trus to 130 trus	Over 10 tons to 130 tons
	250 Hours	250 Hours
	40 terrs and under	40 ters and under
	40 Hours	40 Hours
(ć) Small Telæcopie Boom	15 tors and above	15 ters and above
Cranes (Fixed Cab) (TSS)	-10 Hours	-10 Hours
	Over 5 lons to 15 lons	Over 5 lens to 15 lens
	20 Hours	20 Hours
	5 ions and under	5 tons and under
	8 herus	félhours
2) Articulating Boom Cranes	20 Hours	20 Hours
2) Tower Cranes		
a) Hammerhead	500 Hours	500 Hours
b) Luffèr	500 Hours	500 Hours
c) Solf-Recting	30 Hours	50 Hours
1) Overhend Crunes	•	
a) Cab Operated	40 ffours	40/Hours
b) Pencant/Remote	10 Hours	10 Hours
5) Demicks	20 Hours	500 Hours
Hours of actual crane operating e	vpertence . For all cranes: Time while that grane: and/or a combination of	a the operator is at the controls of
ile, extending and retracting outrigg ranes: It mis utles time while jumpi	s includes time while installing/remo- orsistals increas leaching crane, and rep ing fruct casing the height of the tower	dacing hoisting topo. For tower -
Hours of crane related experience	ter experience may account for erane : Trine as a signalman befor an orten indutor operation, and a combination of	erane mechanic, crane inspector,
calegories of eranex.	· · · · · · · · · · · · · · · · · · ·	

Crane Operator Experience for Cranes Used in the Construction Industry





Crane Related Safety Inspections

43 Safety Inspections





The New Construction Crane Rule

Crane rule status

•Phase One: Crane Certification Crane Certifiers Operator Qualifications

•Phase Two:

Similar to the OSHA Proposal Training, Assembly/Disassembly, Signals, Inspections, Maintenance, Operations.....





Questions?

Contact:

Larry Markee (360) 902-4553 Mala235@Ini.wa.gov

